1



Connect / disconnect clean parts only

2

Do not remove attachment in use

3

Avoid surface contact

4



Clean plug connection
before & after disconnecting